

TALOYA

Ceiling Fan with Light

“What we can offer you is not only a fan
but also an attitude towards life”

Service Mailbox: info@taloya.com



Technical specifications

Ceiling Fan Light

Model NO. 9015

SKU NO.

TLY52-BK-3D-X3

TLY52-WE-3D-X3

TLY52-SW-3D-X3

TLY52-CF-3D-X3

Input: AC120V 60HZ

Motor Type:DC Motor

Fan Power:35W

Light Type:LED

Light Power:8W

Fan Size : 52 inch



WARNING

Disconnect power prior to installation, inspection, or removal
Do not touch when light is on or when it is hot

If there is any problem with the fixture, turn power off and do not attempt to repair unless you are a qualified technician

Do not expose to water or rain


Ensure the lowest point of the fan is no less than 2.1 meters from the ground after it is installed.



ON/OFF switch



⊗ Dimmable switch



Packing List



Hanger Bracket



Canopy



Cover

6" Downrod




Down Rod and Hanger Ball



Boss Cover




Motor



Remote Control



Blade



Screw Pack

Installation Guide

1




Unscrew the 3 screws on the motor rear cover.

2



Remove the rear cover of the motor.

3




Screw the fan blades onto the fan motor.

4



Reinstall the motor rear cover back onto the motor.



5

Unscrew the 2 screws and pins on the motor shaft for fixing.




6

Slide the Canopy and Cover onto the down rod.



7


Thread the wires through the down rod.



8

Screw the screws and pins back into the motor shaft to secure the down rod.

9




Secure the hanger bracket to the ceiling.

10




Hang the assembled fan onto the hanger bracket on the ceiling.
(Note: Snap the notch of the Hanger Ball into the raised area of the hanger bracket)

11




Plug the wire terminals into the controller.

12




Securely connect the green wires on the controller, mounting bracket, and mounting ball to the ground wire in the power supply to ensure proper grounding.

13




Connect the black wire from the fan controller to the live wire and the white wire to the neutral wire.

14




Insert the controller into the gap of the hanger bracket.

15



Installation is complete after secure the canopy and cover.

Ceiling Fan Remote Control Manual



Kindly Reminders:

If the remote control is unable to operate the fan, please follow the steps below to troubleshoot:

1. Check the remote control's battery for proper contact, correct placement and sufficient charge. Low battery voltage can decrease the range and sensitivity of the remote. If the remote control is not used for an extended period, please remove the batteries.
2. Try re-pair the remote control with ceiling fan.

Pairing Method:

Turn on the power, press and hold the "  " button within the first 5 seconds of the light turning on. When you hear the "beep" sound or see the light flashing, the pairing is successful. If you need to pair again, wait for 30 seconds after turning off the power and repeat the above steps.

Input voltage: AC100V-240V 50/60Hz Power by 2×AAA batteries (not included)

The logo consists of the word "TALOYA" in white, uppercase, sans-serif font, centered within a red rounded rectangle.

TALOYA

"What we can offer you is not only a fan
but also an attitude towards life"

info@taloya.com
www.taloya.com